


Section 3.4


Static and Dynamic Stability, Longitudinal Pitch Dynamics




Static Vs. Dynamic Stability

Static Stability

Positive: Quick to return, hard to displace




Negative: Quick to displace, hard to return




Neutral: Stays put




Positive: Slower to return, easier to displace




Negative: Slower to displace, easier to return



Dynamic Stability




Dynamic Stability





$$\text{Period/Time to subside} = \text{damping ratio, } \zeta$$


Static Versus Dynamic Stability (2)



Airframe Static Stability




(b) Statically unstable airplane.



(c) Neutral static stability.


Airframe Dynamic Stability



(a) Statically and dynamically stable.




(b) Statically stable; neutral dynamic stability.



(c) Statically stable; dynamically unstable.

Center of Pressure




•Aerodynamic *Lift, Drag, and Pitching Moment* Can be thought of acting at a single point ... the **Center of Pressure (C_P)** of the vehicle


•Sometimes (*and not quite correctly*) referred to as the **Aerodynamic Center (A_c)**

•*For our purposes applied to an axisymmetric rocket configuration, A_c and C_P are synonymous*

Center of Pressure




*Actual Distributed
Pressure Forces on
Body Surface*



*Equivalent Point Load
with Identical Moment
About CG*


Flight Vehicle Static Stability

- If center of gravity (cg) is forward of the C_p , vehicle responds to a disturbance by producing aerodynamic moment that returns Angle of attack of vehicle towards angle that existed prior to the disturbance. (*static stability*)
- If cg is behind the center of pressure, vehicle will respond to a disturbance by producing an aerodynamic moment that continues to drive angle of attack further away from starting position. (*static instability*)






Static Stability, Rocket Flight Example



- During flight small wind gusts or thrust offsets cause the rocket to "wobble" ... change attitude
- Rocket rotates about center of gravity (cg)
- Lift and drag both act through center of pressure (Cp)
- When cp is behind cg , aerodynamic forces provide a "restoring force" ... rocket is said to be "statically stable"
- When Cp ahead of cg , aerodynamic forces provide a "destabilizing force" ... rocket is said to be "unstable"
- *Condition for a statically for a stable rocket is that center of pressure must be located behind longitudinal center of gravity.*






Static Stability, Rocket Flight Example (2)



Static Stability, Rocket Flight Example (3)



Weather Vane Analogy of Static Stability



Static Margin and Pitching Moment


- *Static margin* used to characterize static stability and controllability of aircraft and missiles.
- *For aircraft systems ... Static margin* defined as non-dimensional distance between center of gravity (cg) and aerodynamic center (ac) of the aircraft.
- **For missile systems ... Static margin** defined as non-dimensional distance between center of gravity (cg) and the center of pressure (Cp).
- *Static Stability* requires that the pitching moment C_m about the rotation point, become negative as we increase C_L :

Pitching Moment Analysis

$C_{m0} \rightarrow$ pitching moment about C_p

$C_{m(\alpha)} \rightarrow$ pitching moment about cg

$c_{ref} =$ "chord" reference length



Sum Moments about cg

$$C_m(\alpha) = C_{m_0} + \left(\frac{X_{cg} - X_{cp}}{c_{ref}} \right) \cdot (C_L \cdot \cos \alpha + C_D \cdot \sin \alpha)$$

$$\rightarrow \text{Define ... } X_{sm} = \left(\frac{X_{cp} - X_{cg}}{c_{ref}} \right) \rightarrow C_m(\alpha) = C_{m_0} - X_{sm} \cdot (C_L \cdot \cos \alpha + C_D \cdot \sin \alpha)$$

$\rightarrow$ Linearize Pitching Moment Equation

$$\dots C_m(\alpha) = C_{m_0} + \frac{\partial C_m}{\partial \alpha} \cdot \alpha$$

Pitching Moment Analysis (2)

$$\rightarrow \text{Define ... } C_{m_\alpha} = \frac{\partial C_m}{\partial \alpha} = -X_{sm} \cdot \left(\frac{\partial C_L}{\partial \alpha} \cdot \cos \alpha - C_L \cdot \sin \alpha + \frac{\partial C_D}{\partial \alpha} \cdot \sin \alpha + C_D \cdot \cos \alpha \right) =$$

$$-X_{sm} \cdot \left[\left(\frac{\partial C_L}{\partial \alpha} + C_D \right) \cdot \cos \alpha - \left(C_L - \frac{\partial C_D}{\partial \alpha} \right) \cdot \sin \alpha \right]$$

$$\rightarrow \text{Small } \alpha \text{ approximation ... } \frac{\partial C_m}{\partial \alpha} = -X_{sm} \cdot \left(\left(\frac{\partial C_L}{\partial \alpha} + C_D \right) - \left(C_L - \frac{\partial C_D}{\partial \alpha} \right) \cdot \alpha \right)$$

$$\rightarrow \text{Neglect } \alpha^2 \text{ term ... } C_m(\alpha) = C_{m_0} - X_{sm} \cdot \left(\frac{\partial C_L}{\partial \alpha} + C_D \right) \cdot \alpha - \left(C_L - \frac{\partial C_D}{\partial \alpha} \right) \cdot \alpha^2$$

$$\rightarrow C_{m_\alpha} = \frac{\partial C_m}{\partial \alpha} = -X_{sm} \cdot \left(\frac{\partial C_L}{\partial \alpha} + C_D \right)$$

Pitching Moment Analysis ⁽³⁾

Linear Airfoil Theory


$$C_L = C_{L_0} + \frac{\partial C_L}{\partial \alpha} \cdot \alpha \equiv C_{L_0} + C_{L_0} + \frac{\partial C_L}{\partial \alpha} \cdot \alpha$$

$$C_D = C_{D_0} + \frac{C_L^2}{\pi \cdot \varepsilon \cdot A_r}$$


$$\rightarrow \left[\begin{array}{c} \frac{\partial C_L}{\partial \alpha} \\ C_D \end{array} \right] > 0$$

$$\frac{\partial C_m}{\partial \alpha} \rightarrow "C_{m_\alpha}" \dots \text{Ideally...}$$

$$C_{m_\alpha} = -X_{sm} \left(\frac{\partial C_L}{\partial \alpha} + C_D \right) \rightarrow \left[\begin{array}{c} \frac{\partial C_L}{\partial \alpha} \\ C_D \end{array} \right] > 0 \rightarrow X_{sm} > 0 \dots \begin{array}{c} \text{static} \\ \text{stability} \end{array} \rightarrow \boxed{C_{m_\alpha} < 0 \dots \begin{array}{c} \text{static} \\ \text{stability} \end{array}}$$




Pitching Moment Analysis (4)




For a Rocket Static margin is the distance between the CG and the C_P ; divided by body tube diameter.

$$X_{sm} > 0 \dots \begin{array}{c} \textit{static} \\ \textit{stability} \end{array} \rightarrow C_{m_\alpha} < 0 \dots \begin{array}{c} \textit{static} \\ \textit{stability} \end{array}$$


Pitching Moment Analysis (6)




- Even $X_{sm} > 0$ (static stability) rockets become unstable at higher angles of attack
- “Strong stability” region limited to very low angle of attack range




Pitching Moment Analysis (5)





Achieving Static Stability



Static Margin = Degree of Static Stability




How Much Static Stability?




*One Second
After Launch*

How Much Static Stability? ⁽²⁾



(a) Modest Stability $\rightarrow$ N May Have Significant Effect on Trajectory



(b) Strong Stability $\rightarrow$ N Small (Rocket Quickly Reorients to $\alpha = 0$)

You Probably Want Strong Stability to Enable Accurate Trajectory Calculation Without Modeling N

Note: Achieving Suitable Crosswind Flight Might Require Weaker Stability = More Difficult Simulation = More "Expensive" Rocket


Calculating the Static Margin

- Key to calculating static margin is estimate of location of longitudinal center of pressure at low angles of attack
- [Barrowman equations](#) provide simple, accurate technique for Axi-symmetric rockets
- cg is measured as the longitudinal balance point of the rocket.
- As a rule of thumb, Cp distance should be aft of the cg by at least one rocket diameter. -- "*One Caliber stability*".

Calculating the Static Margin ⁽²⁾

N -- total normal FORCE

n -- sectional normal pressure differential



- Neglect Small Contribution of Body (Valid for Small Angles Only)
- Compute Point Force and "Center of Pressure" For Nose and Tail Distributed Loads Independently (Assume No Aerodynamic Interactions / Interference) ... + transitions + boat tail

$$N = \int_{x=0}^{x=L} n(x)dx \approx \int_{NOSE} n(x)dx + 0 + \int_{TAIL} n(x)dx$$

Calculating the Static Margin ⁽³⁾

$$C_N @ \frac{N}{\frac{1}{2} \rho V^2 A} \approx = \frac{N_{nose} + N_{tail} + N_{trns} + N_{boat} + \dots}{\bar{q} \cdot A_{ref}} =$$

$$C_{N_{nose}} + C_{N_{tail}} + C_{N_{trns}} + C_{N_{boat}} + \dots$$



For Small Angles of Attack, α , Force Coefficients Are Linearly Related to α

$$C_N = C_{N_\alpha} \alpha = \left(C_{N_{\alpha_{nose}}} + C_{N_{\alpha_{tail}}} + C_{N_{\alpha_{trns}}} + C_{N_{\alpha_{boat}}} + \dots \right) \cdot \alpha$$

Simplified “Barrowman Equations” Give Formulas for Derivatives on RHS in Terms of Nose, Fin & Transition Geometry

Calculating the Static Margin (4)

Parameter Definitions



L_N = length of nose

d_{max} = *maximum body diameter*

d_F = diameter at front of transition

d_R = diameter at rear of transition

L_T = length of transition

X_P = distance from tip of nose to front of transition

C_R = fin root chord

C_T = fin tip chord

S = fin semispan

L_F = length of fin mid-chord line

R = radius of body at aft end

X_R = distance between fin root leading edge and fin tip leading edge parallel to body

X_B = distance from nose tip to fin root chord leading edge

N = number of fins

Calculating the Static Margin (3)

X_N = center of pressure location for nose section

Nose Cone Terms

- $(C_N)_N = 2$
- For Cone: $X_N = 0.666L_N$
- For Ogive: $X_N = 0.466L_N$

X_T = center of pressure location for transitions

$(C_N)_N$ = normal force derivative for nose

$(C_N)_T$ = normal force derivative for transition

Conical Transition Terms

$$(C_N)_T = 2 \left[\left(\frac{d_R}{d_{\max}} \right)^2 - \left(\frac{d_F}{d_{\max}} \right)^2 \right] \Rightarrow X_T = X_P + \frac{L_T}{3} \left[1 + \frac{1 - \frac{d_F}{d_R}}{1 - \left(\frac{d_F}{d_R} \right)^2} \right]$$


Calculating the Static Margin (4)

Fin Terms

XF = center of pressure location for fin groups

$(CN_a)F$ = Normal force derivative for fin group

$$(C_{N_a})_F = \left[1 + \frac{R}{S+R} \right] \left[\frac{4N \left(\frac{S}{d_{\max}} \right)^2}{1 + \sqrt{1 + \left(\frac{2L_F}{C_R + C_T} \right)^2}} \right] \longrightarrow X_F = X_B + \frac{X_R (C_R + 2C_T)}{3 (C_R + C_T)} + \frac{1}{6} \left[(C_R + C_T) - \frac{(C_R C_T)}{(C_R + C_T)} \right]$$

Finding the Center of Pressure

- Sum up coefficients:

$$(C_{N_a})_R = (C_{N_a})_N + (C_{N_a})_T + (C_{N_a})_F$$

- Find CP Distance from Nose Tip:

$$X_{cp} = \frac{(C_{N_a})_N X_N + (C_{N_a})_T X_T + (C_{N_a})_F X_F}{(C_{N_a})_R}$$

Static Margin (X_{sm}) =


$$(X_{cp} - X_{cg}) / d_{\max}$$

$(CN_a)R$ = total normal force derivative

***X – measured aft from
nose of vehicle***

$$\text{Small } \alpha \rightarrow C_{N_\alpha} \cong C_{L_\alpha}$$

Example: Stable Static Margin Vehicle



$$L_N = 20 \text{ cm}$$

$$d_{\max} = 10 \text{ cm}$$

$$d_F = 10 \text{ cm}$$

$$d_R = 8 \text{ cm}$$

$$L_T = 5 \text{ cm}$$

$$X_P = 30 \text{ cm}$$

$$C_R = 10 \text{ cm}$$

$$C_T = 5 \text{ cm}$$

$$S = 10 \text{ cm}$$

$$L_F = 12 \text{ cm}$$

$$R = 4 \text{ cm}$$

$$X_R = 16 \text{ cm}$$

$$X_B = 50 \text{ cm}$$

$$N = 3$$

Output parameters

Nosecone	Fins
CNN	CNF
2	6.12587
XN, cm	XF, cm
9.32	56.9921
Conical Transition	Total
CNT	CNR
-0.72	7.40587
XT, cm	Xcp, cm
32.4074	46.5081


Static Margin

1.85081

CG, cm from nose

28

Ogive Nose





Output parameters

CG, cm from nose

25

Rotational Dynamics of a Rigid Body.





Simplified Pitch Axis Dynamics

General Rotational Dynamics

$$\begin{bmatrix} I_x & -I_{xy} & -I_{xz} \\ -I_{xy} & I_y & -I_{yz} \\ -I_{xz} & -I_{yz} & I_z \end{bmatrix} \cdot \begin{bmatrix} \dot{p} \\ \dot{q} \\ \dot{r} \end{bmatrix} = \begin{pmatrix} q \cdot r (I_y - I_z) + (q^2 - r^2) I_{yz} + p \cdot q (I_{xz}) - r \cdot p (I_{xy}) \\ r \cdot p (I_z - I_x) + (r^2 - p^2) I_{xz} + q \cdot r (I_{xy}) - p \cdot q (I_{yz}) \\ p \cdot q (I_x - I_y) + (p^2 - q^2) I_{xy} + r \cdot p (I_{yz}) - q \cdot r (I_{xz}) \end{pmatrix} + \begin{bmatrix} M_x \\ M_y \\ M_z \end{bmatrix}$$

Collected Equations

$$\begin{bmatrix} I_{xx} & -I_{xy} & -I_{xz} \\ -I_{xy} & I_{yy} & -I_{yz} \\ -I_{xz} & -I_{yz} & I_{zz} \end{bmatrix} \cdot \begin{bmatrix} \dot{p} \\ \dot{q} \\ \dot{r} \end{bmatrix} = \begin{bmatrix} (I_{yy} - I_{zz}) \cdot q \cdot r + I_{yz} \cdot (q^2 - r^2) + I_{xz} \cdot p \cdot q - I_{xy} \cdot p \cdot r \\ (I_{zz} - I_{xx}) \cdot p \cdot r + I_{xz} \cdot (r^2 - p^2) + I_{xy} \cdot q \cdot r - I_{yz} \cdot p \cdot q \\ (I_{xx} - I_{yy}) \cdot p \cdot q + I_{xy} \cdot (p^2 - q^2) + I_{yz} \cdot p \cdot r - I_{xz} \cdot q \cdot r \end{bmatrix} + \begin{bmatrix} M_x \\ L_y \\ N_z \end{bmatrix}$$

Principal Axes

$$I \approx \text{Real, symmetrix} \rightarrow \text{Find Axis Where} \rightarrow \begin{bmatrix} I_{xx} & -I_{xy} & -I_{xz} \\ -I_{xy} & I_{yy} & -I_{yz} \\ -I_{xz} & -I_{yz} & I_{zz} \end{bmatrix} = U^T \cdot \Gamma \cdot U \rightarrow \Gamma = \begin{bmatrix} I'_{xx} & 0 & 0 \\ 0 & I'_{yy} & 0 \\ 0 & 0 & I'_{zz} \end{bmatrix}$$

with no inertia cross products

Euler's Equations $\rightarrow I_{xy} = I_{xz} = I_{yz} = 0 \rightarrow \text{Simplify}$

$$\begin{bmatrix} I_{xx} \cdot \dot{p} \\ I_{yy} \cdot \dot{q} \\ I_{zz} \cdot \dot{r} \end{bmatrix} = \begin{bmatrix} (I_{yy} - I_{zz}) \cdot q \cdot r \\ (I_{zz} - I_{xx}) \cdot p \cdot r \\ (I_{xx} - I_{yy}) \cdot p \cdot q \end{bmatrix} + \begin{bmatrix} M_x \\ L_y \\ N_z \end{bmatrix} \rightarrow \begin{bmatrix} \dot{p} = \left(\frac{I_{yy} - I_{zz}}{I_{xx}} \right) \cdot q \cdot r + \frac{M_x}{I_{xx}} \\ \dot{q} = \left(\frac{I_{zz} - I_{xx}}{I_{yy}} \right) \cdot p \cdot r + \frac{L_y}{I_{yy}} \\ \dot{r} = \left(\frac{I_{xx} - I_{yy}}{I_{zz}} \right) \cdot p \cdot q + \frac{N_z}{I_{zz}} \end{bmatrix}$$

Collected Euler Equations

$$\begin{bmatrix} \dot{p} \\ \dot{q} \\ \dot{r} \\ \dot{\phi} \\ \dot{\theta} \\ \dot{\psi} \end{bmatrix} = \begin{bmatrix} \left(\frac{I_{yy} - I_{zz}}{I_{xx}} \right) \cdot q \cdot r \\ \left(\frac{I_{zz} - I_{xx}}{I_{yy}} \right) \cdot p \cdot r \\ \left(\frac{I_{xx} - I_{yy}}{I_{zz}} \right) \cdot p \cdot q \\ p + \tan \theta \cdot \sin \phi \cdot q + \tan \theta \cdot \cos \phi \cdot r \\ \cos \phi \cdot q - \sin \phi \cdot r \\ \frac{\sin \phi}{\cos \theta} \cdot q + \frac{\cos \phi}{\cos \theta} \cdot r \end{bmatrix} + \begin{bmatrix} \frac{M_x}{I_{xx}} \\ \frac{M_y}{I_{yy}} \\ \frac{N_z}{I_{zz}} \\ 0 \\ 0 \\ 0 \end{bmatrix} + \text{disturbance torques}$$

Simplified Pitch Axis Dynamics

General Rotational Dynamics

$$\begin{bmatrix} I_x & -I_{xy} & -I_{xz} \\ -I_{xy} & I_y & -I_{yz} \\ -I_{xz} & -I_{yz} & I_z \end{bmatrix} \cdot \begin{bmatrix} \dot{p} \\ \dot{q} \\ \dot{r} \end{bmatrix} = \begin{pmatrix} q \cdot r (I_y - I_z) + (q^2 - r^2) I_{yz} + p \cdot q (I_{xz}) - r \cdot p (I_{xy}) \\ r \cdot p (I_z - I_x) + (r^2 - p^2) I_{xz} + q \cdot r (I_{xy}) - p \cdot q (I_{yz}) \\ p \cdot q (I_x - I_y) + (p^2 - q^2) I_{xy} + r \cdot p (I_{yz}) - q \cdot r (I_{xz}) \end{pmatrix} + \begin{bmatrix} M_x \\ M_y \\ M_z \end{bmatrix}$$

$$\rightarrow \ddot{\theta} = \frac{M_y}{I_y} + r \cdot p \frac{(I_z - I_x)}{I_y}$$

Neglect Cross Products of Inertia

*Forcing
moment*

*Second order Disturbance torque
(neglected when r, p are small)*

Simplified Pitch Axis Dynamics (2)

Neglecting Disturbance torques

$$\ddot{\theta} = \dot{q} = \frac{M_y}{I_y} \rightarrow M_y \approx \text{"pitching moment"}$$

Consider Only Pitch Axis Dynamics for axi-symmetrix Missile

"pitching moment coefficient" $\equiv C_m = \frac{M_y}{\bar{q} \cdot A_{ref} \cdot c_{ref}}$

$$\bar{q} = \left(\frac{1}{2} \cdot \rho \cdot V^2 \right)$$

$$A_{ref} = \frac{\pi}{4} \cdot D_{ref}^2$$

"reference length" $\rightarrow c_{ref} = D_{max}$

Check Units

$$\frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \sim \frac{\frac{Nt}{m^2} \cdot m^2 \cdot m}{kg \cdot m^2} \sim \left(\frac{kg \cdot m}{sec^2 m^2} \cdot m^2 \cdot m \right) \cdot \frac{1}{kg \cdot m^2} \sim \frac{1}{sec^2}$$


Simplified Pitch Axis Dynamics (3)

Pitching moment about cg

$$\dot{q} = \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_m$$

Depends on angle of attack


*Gravity acts at cg and
Cannot induce pitching moment*



Simplified Pitch Axis Dynamics (4)

$$\ddot{\theta} = \dot{q} = \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_m$$

*Depends on angle of attack +
Control inputs*




It can also be shown that ... (NASA RP-1168 pp 10-22) that for angle of attack

$$\dot{\alpha} = -\frac{\bar{q} \cdot A_{ref}}{m \cdot V} \cdot C_L + q + \frac{g_{(r)}}{V} \cos(\theta - \alpha) - \frac{F_{thrust} \sin \alpha}{m \cdot V}$$

See appendix I for derivation

Collected, Simplified Longitudinal Axis-Dynamics (5)

$$\begin{bmatrix} \dot{\alpha} \\ \dot{q} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref}}{m \cdot V} \cdot C_L + q + \frac{g_{(r)}}{V} \cos(\theta - \alpha) - \frac{F_{thrust} \sin \alpha}{m \cdot V} \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_m \\ q \end{bmatrix}$$


Linear Analysis of Longitudinal Axis-Dynamics

Start with

$$\begin{bmatrix} \dot{\alpha} \\ \dot{q} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref}}{m \cdot V} \cdot C_L + q + \frac{g(r)}{V} \cos(\theta - \alpha) - \frac{F_{thrust} \sin \alpha}{m \cdot V} \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_m \\ q \end{bmatrix}$$

$$\begin{array}{l} \alpha \rightarrow \text{small} \\ C_L \approx C_{L_\alpha} \cdot \alpha \\ C_m \approx C_{m_\alpha} \cdot \alpha + C_{m_q} \cdot q \\ q = \dot{\theta} \\ \dot{q} = \ddot{\theta} \end{array} \rightarrow \begin{bmatrix} \dot{\alpha} \\ \dot{q} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref} \cdot C_{L_\alpha} + T_{thrust}}{m \cdot V_\infty} & 1 & 0 \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_\alpha} & \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} & 0 \\ 0 & 1 & 0 \end{bmatrix} \cdot \begin{bmatrix} \alpha \\ q \\ \theta \end{bmatrix} + \begin{bmatrix} \frac{g \cdot \cos(\theta)}{V_\infty} \\ 0 \\ 0 \end{bmatrix}$$

$C_{m_\alpha} \rightarrow$ "stability derivative"

$C_{m_q} \rightarrow$ "damping derivative"

Linear Analysis (2)

Let $q = \dot{\theta}$ & Reorder States ...
 $\dot{q} = \ddot{\theta}$

$$\begin{bmatrix} \dot{\alpha} \\ \dot{q} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} & 1 & 0 \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_{\alpha}} & \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} & 0 \\ 0 & 1 & 0 \end{bmatrix} \cdot \begin{bmatrix} \alpha \\ q \\ \theta \end{bmatrix} + \begin{bmatrix} \frac{g \cdot \cos(\theta)}{V_{\infty}} \\ 0 \\ 0 \end{bmatrix}$$



$$\begin{bmatrix} \dot{\alpha} \\ \dot{\theta} \\ \ddot{\theta} \end{bmatrix} = \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} & 0 & 1 \\ 0 & 0 & 1 \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_{\alpha}} & 0 & \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} \end{bmatrix} \cdot \begin{bmatrix} \alpha \\ \theta \\ \dot{\theta} \end{bmatrix} + \begin{bmatrix} \frac{g \cdot \cos(\theta)}{V_{\infty}} \\ 0 \\ 0 \end{bmatrix}$$

Linear Analysis (3)

Write as $\dot{X} = A \cdot X + G(t)$

$$\begin{bmatrix} \dot{\alpha} \\ \dot{\theta} \\ \ddot{\theta} \end{bmatrix} = \frac{d}{dt} \begin{bmatrix} \alpha \\ \theta \\ \dot{\theta} \end{bmatrix} \rightarrow X = \begin{bmatrix} \alpha \\ \theta \\ \dot{\theta} \end{bmatrix} \rightarrow A = \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} & 0 & 1 \\ 0 & 0 & 1 \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_{\alpha}} & 0 & \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} \end{bmatrix} \rightarrow G(t) = \begin{bmatrix} \frac{g \cdot \cos(\theta)}{V_{\infty}} \\ 0 \\ 0 \end{bmatrix}$$

Look at Eigenvalues of Linearized System

$$Det[A - \lambda \cdot I] = 0 \rightarrow \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} - \lambda & 0 & 1 \\ 0 & -\lambda & 1 \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_{\alpha}} & 0 & \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} - \lambda \end{bmatrix} = 0$$

Linear Analysis (4)

Eigen Values

$$Det[A - \lambda \cdot I] = 0 \rightarrow \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} - \lambda & 0 & 1 \\ 0 & -\lambda & 1 \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_{\alpha}} & 0 & \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} - \lambda \end{bmatrix} = 0$$

$$-\left(\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} + \lambda\right) \cdot \left(\lambda^2 - \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} \cdot \lambda\right) + \left(\frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_{\alpha}}\right) \cdot \lambda = 0$$

→ divide thru by $-\lambda$

$$\left(\lambda + \frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}}\right) \cdot \left(\lambda - \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q}\right) - \left(\frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_{\alpha}}\right) = 0$$

Linear Analysis (4)

$$\left(\lambda + \frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} \right) \cdot \left(\lambda - \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} \right) - \left(\frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_{\alpha}} \right) = 0$$

Expand and Collect Terms to give Characteristic Equation for Linearized System

$$\lambda^2 + \left(\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} - \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} \right) \cdot \lambda - \left(\frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \right) \cdot \left[\left(\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} \right) \cdot C_{m_q} + C_{m_{\alpha}} \right] = 0$$

Form like: $\lambda^2 + 2 \cdot \zeta \cdot \omega_n \cdot \lambda + \omega_n^2 = 0$


$$\rightarrow \omega_n = \sqrt{-\left(\frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \right) \cdot \left[\left(\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} \right) \cdot C_{m_q} + C_{m_{\alpha}} \right]}$$

Natural Frequency

$$\frac{(2 \cdot \zeta \cdot \omega_n)^2}{\omega_n^2} \rightarrow \zeta = \sqrt{\frac{\frac{1}{4} \left(\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} - \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_{m_q} \right)^2}{-\left(\frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \right) \cdot \left[\left(\frac{\bar{q} \cdot A_{ref} \cdot C_{L\alpha} + T_{thrust}}{m \cdot V_{\infty}} \right) \cdot C_{m_q} + C_{m_{\alpha}} \right]}}$$

Damping ratio

Estimating the Damping Derivatives



$$\text{Small } \alpha \rightarrow C_{N_\alpha} \cong C_{L_\alpha} \rightarrow C_N = C_{L_\alpha} \cdot \left(\frac{X_{cp} - X_{cg}}{V_\infty} \right) \cdot q$$

$$C_m = -C_N \cdot \frac{(X_{cp} - X_{cg})}{c_{ref}} = -C_{L_\alpha} \cdot \left(\frac{(X_{cp} - X_{cg})^2}{V_\infty} \right) \cdot \frac{q}{c_{ref}} = -C_{L_\alpha} \cdot \left(\frac{(X_{cp} - X_{cg})^2}{V_\infty c_{ref}^2} \right) \cdot q \cdot c_{ref} = -C_{L_\alpha} \cdot (X_{sm}^2) \cdot \frac{c_{ref}}{V_\infty} \cdot q$$

$$\delta C_m = \frac{\partial C_m}{\partial q} \cdot q = C_{m_q} \cdot q = -C_{L_\alpha} \cdot (X_{sm}^2) \cdot \frac{c_{ref}}{V_\infty} \cdot q \rightarrow \boxed{C_{m_q} = -C_{L_\alpha} \cdot (X_{sm}^2) \cdot \frac{c_{ref}}{V_\infty}}$$

$$\boxed{C_{m_q} = -C_{L_\alpha} \cdot (X_{sm}^2) \cdot \frac{c_{ref}}{V_\infty}} \rightarrow \text{pitch damping opposes motion } \textcircled{R} \text{ i.e. always negative}$$

Collected Longitudinal Equations of Motion

$$\begin{bmatrix} \dot{V}_r \\ \dot{V}_v \\ \dot{r} \\ \dot{v} \\ \dot{x} \\ \dot{\alpha} \\ \dot{q} \\ \dot{\theta} \\ \dot{m} \end{bmatrix} = \begin{bmatrix} \left(\frac{V_v^2}{r} \right) + \left(\frac{\bar{q} \cdot A_{ref}}{m} \right) \cdot (C_L \cos \gamma - C_D \sin \gamma) + \left(\frac{F_{thrust} \sin \theta}{m} \right) - g_{(r)} \\ - \left(\frac{V_r \cdot V_v}{r} \right) - \left(\frac{\bar{q} \cdot A_{ref}}{m} \right) \cdot (C_L \sin \gamma + C_D \cos \gamma) + \left(\frac{F_{thrust} \cos \theta}{m} \right) \\ V_r \\ \frac{V_v}{r} \\ V_v \\ - \frac{\bar{q} \cdot A_{ref}}{m \cdot V} \cdot C_L + q + \frac{g_{(h)}}{V} \cos(\gamma) - \frac{F_{thrust} \sin \alpha}{m \cdot V} \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_m \\ q \\ - \frac{F_{thrust}}{g_0 \cdot I_{sp}} \end{bmatrix}$$

Can we simplify this “mess”?

$$\begin{aligned} g_{(r)} &= \frac{\mu}{r^2} \\ \gamma &= \tan^{-1} \frac{V_r}{V_v} = \theta - \alpha \\ \dot{x} &= r \cdot \dot{v} \\ V &= \sqrt{V_r^2 + V_v^2} \\ \bar{q} &= \frac{1}{2} \cdot \rho_{(h)} \cdot V^2 \\ h &= r - R_{earth} \end{aligned}$$

Simplified Longitudinal Equations of Motion

$$\begin{bmatrix} \dot{\alpha} \\ \dot{q} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref}}{m \cdot V} \cdot C_L + q + \frac{g(r)}{V} \cos(\theta - \alpha) - \frac{F_{thrust} \sin \alpha}{m \cdot V} \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_m \\ q \end{bmatrix}$$

Augment with longitudinal Acceleration Equation (See Appendix II)

$$\dot{V}_{\infty} = \frac{T_{thrust} \cdot \cos \alpha}{m} - g \cdot \sin(\theta - \alpha) - \frac{\bar{q} \cdot A_{ref} \cdot C_D}{m}$$

Complete with altitude and downrange

$$\dot{h} = V_{\infty} \cdot \sin \gamma = V_{\infty} \cdot \sin(\theta - \alpha)$$

$$\dot{x} = V_{\infty} \cdot \cos \gamma = V_{\infty} \cdot \cos(\theta - \alpha)$$

Simplified Longitudinal Equations of Motion

Collected Body-Axis Equations

$$\begin{bmatrix} \dot{V}_{\infty} \\ \dot{\alpha} \\ \dot{\theta} \\ \dot{q} \\ \dot{h} \\ \dot{x} \\ \dot{m} \end{bmatrix} = \begin{bmatrix} \frac{T_{thrust} \cdot \cos \alpha}{m} - g \cdot \sin(\theta - \alpha) - \frac{\bar{q} \cdot A_{ref} \cdot C_D}{m} \\ \dot{\alpha} = q + \frac{g \cdot \cos(\theta - \alpha)}{V_{\infty}} - \frac{\bar{q} \cdot A_{ref} \cdot C_L + T_{thrust} \cdot \sin \alpha}{m \cdot V_{\infty}} \\ q \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref} \cdot C_m}{I_{yy}} \\ V_{\infty} \sin(\theta - \alpha) \\ V_{\infty} \cos(\theta - \alpha) \\ -\frac{T_{thrust}}{g_0 \cdot I_{sp}} \end{bmatrix}$$

$$C_L = C_L(\alpha) \simeq C_{N_{\alpha}} \cdot \alpha$$

$$C_m = C_m(\alpha, q) \approx C_{m_{\alpha}} \cdot \alpha + C_{mq} \cdot q =$$

$$-X_{sm} \cdot (C_{N_{\alpha}} + C_D) \cdot \alpha - X_{sm}^2 \cdot \left(C_{N_{\alpha}} \cdot \frac{c_{ref}}{V_{\infty}} \right) \cdot q$$

Model Comparison

Body Axis with Pitch Dynamics Model

One extra degree of freedom

$$\begin{bmatrix} \dot{V}_\infty \\ \dot{\alpha} \\ \dot{\theta} \\ \dot{q} \\ \dot{h} \\ \dot{x} \\ \dot{m} \end{bmatrix} = \begin{bmatrix} \frac{T_{thrust} \cdot \cos \alpha}{m} - g \cdot \sin(\theta - \alpha) - \frac{\bar{q} \cdot A_{ref} \cdot C_D}{m} \\ \dot{\alpha} = q + \frac{g \cdot \cos(\theta - \alpha)}{V_\infty} - \frac{\bar{q} \cdot A_{ref} \cdot C_L + T_{thrust} \cdot \sin \alpha}{m \cdot V_\infty} \\ q \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref} \cdot C_m}{I_{yy}} \\ V_\infty \sin(\theta - \alpha) \\ V_\infty \cos(\theta - \alpha) \\ -\frac{T_{thrust}}{g_0 \cdot I_{sp}} \end{bmatrix}$$

Local Vertical/Local Horizontal Ballistic Model

$$\begin{bmatrix} \dot{V}_r \\ \dot{V}_v \\ \dot{r} \\ \dot{v} \\ \dot{m} \end{bmatrix} = \begin{bmatrix} \frac{V_v^2}{r} - \frac{\mu}{r^2} + \left[\frac{F_{thrust}}{m} - \frac{\rho V_\infty^2}{2\beta} \right] \sin(\gamma) \\ -\frac{V_r V_v}{r} + \left[\frac{F_{thrust}}{m} - \frac{\rho V_\infty^2}{2\beta} \right] \cos(\gamma) \\ V_r \\ \frac{V_v}{r} \\ -\frac{F_{thrust}}{g_0 I_{sp}} \end{bmatrix} \Big|_{\alpha=0}$$

$$\gamma = \tan^{-1} \left[\frac{V_x}{V_v} \right]$$

$$\beta = \frac{M}{C_D \cdot A_{ref}}$$


$$\dot{X} = f[X, F_{thrust}]$$

$$\vec{X} = \begin{bmatrix} V_r \\ V_v \\ r \\ v \\ M \end{bmatrix}$$

$$\left(\dot{\vec{X}} \right) = \begin{bmatrix} \dot{V}_r \\ \dot{V}_v \\ \dot{r} \\ \dot{v} \\ -\dot{m}_{motor} \end{bmatrix}$$

Example Calculation

Rocket Dimensions 2



Fin Coordinate Array

0

Root Length, cm 25	Leading Edge Taper angle, deg 25	Leading edge longitudinal coordinate, 175	Rotate Rocker Roll Axis, deg. 30
Width, cm 35	Trailing Edge Taper Angle, deg 0	Distance from Centerline, cm 10	
Fin Leading Edge Thickness, cm 0.5	# OF FINS 3	Mean fin Angle of Attack, deg. 1	ROTATE Fins? 2

Nose Cone
Length, cm # Axial Nose Points
70 119

Body Tube
Sections, Start, End
Diameters, cm

0	35	35
0	35	20
	20	20
	0	0

Body Tube
Sections,
Lengths, cm

0	40
	15
	80
	0

Body Tube
Sections,
of Points

0	15
	15
	15

Boat Tail
Length, cm

10

Boat Tail
End diameter

15


Boat tail points

15

Approximate cg., cm

100

Example Calculation (2)



Parameter Definitions

L_N = length of nose
 d = diameter at base of nose
 d_F = diameter at front of transition
 d_R = diameter at rear of transition
 L_T = length of transition
 X_P = distance from tip of nose to front of transition
 C_R = fin root chord
 C_T = fin tip chord
 S = fin semispan
 L_F = length of fin mid-chord line
 R = radius of body at aft end
 X_R = distance between fin root leading edge and fin tip leading edge parallel to body
 X_B = distance from nose tip to fin root chord leading edge
 N = number of fins

CG, cm from nose
100

Noze Shape
☒ Ogive
☐ Conical

Parameter Definitions, cm

0	70
	35
	35
	20
	15
	110
	25
	8.6792
	35
	36.809
	10
	14.791
	175
	3

Example Calculation ⁽²⁾

Fin Coefficients

Barrowman ...


$$(C_N)_{\alpha_F} = \left[1 + \frac{R}{S+R} \right] \left[\frac{4N \left(\frac{S}{d_{\max}} \right)^2}{1 + \sqrt{1 + \left(\frac{2L_F}{C_R + C_T} \right)^2}} \right] = \left(1 + \frac{10}{(10 + 35)} \right) \left(\frac{4 \left(\frac{35}{35} \right)^2}{1 + \left(1 + \left(\frac{2 \cdot 36.8091}{25 + 8.67923} \right)^2 \right)^{0.5}} \right)^3 = 4.30898$$

Helmbold ...

$$AR = \frac{LF^2}{A_{fin}} = \frac{36.8091^2}{589.387} = 2.29885$$

$$C_{L_\alpha} = \frac{2\pi \cdot A_R}{2 + \sqrt{A_R^2 + 4}} \times \frac{N_{fins}}{2} = \frac{2\pi 2.29885}{2 + (2.29885^2 + 4)^{0.5}} \frac{3}{2} = 4.29281$$

*Effective C_L for
4 Fin
Configuration*



**4-Fin Rocket Tail End Looking
Forward**

Effective C_L for 4 Fin Configuration

$$w \cdot \cos \phi \rightarrow \alpha_N = \frac{w \cdot \cos \phi}{u} = \alpha \cdot \cos \phi$$

$$C_L = C_{N_\alpha} \cdot \cos \phi \cdot \alpha \cdot \cos \phi = C_N \cdot \cos^2 \phi$$

$$\alpha_N = \frac{w \cdot \sin \phi}{u} = \alpha \cdot \sin \phi$$


$$C_L = C_{N_\alpha} \cdot \sin \phi \cdot \alpha \cdot \sin \phi = C_N \cdot \sin^2 \phi$$

$$C_{L_{effective}} = \sum C_{L_i} = C_N \cdot \cos^2 \phi + C_N \cdot \sin^2 \phi + C_N \cdot \sin^2 \phi + C_N \cdot \cos^2 \phi$$

$$= 2 \cdot C_N \cdot (\cos^2 \phi + \sin^2 \phi)$$

$$\rightarrow \boxed{C_{L_{effective}} = \frac{1}{2} \cdot N \cdot C_N \rightarrow N = 4}$$

Effective C_L for 3 Fin Configuration



3-Fin Rocket Tail End Looking Forward

Effective C_L for 3 Fin Configuration

$$C_L = C_{N_\alpha} \cdot \cos(\phi + 30^\circ) \cdot \alpha \cdot \cos(\phi + 30^\circ) = C_N \cdot c \cos^2(\phi + 30^\circ)$$

$$C_L = C_{N_\alpha} \cdot \cos(\phi - 30^\circ) \cdot \alpha \cdot \cos(\phi - 30^\circ) = C_N \cdot c \cos^2(\phi - 30^\circ)$$

$$C_{L_{\text{effective}}} = \sum C_{L_i} = C_N \cdot c \cos^2(\phi + 30^\circ) + C_N \cdot c \cos^2(\phi - 30^\circ) + C_N \cdot \sin^2 \phi$$

$$c \cos^2(\phi + 30^\circ) = (\cos \phi \cos 30^\circ - \sin \phi \sin 30^\circ)^2 = \left(\frac{\sqrt{3}}{2} \cos \phi - \frac{1}{2} \sin \phi \right)^2 = \frac{3}{4} \cos^2 \phi - \frac{\sqrt{3}}{2} \cos \phi \sin \phi + \frac{1}{4} \sin^2 \phi$$

$$c \cos^2(\phi - 30^\circ) = (\cos \phi \cos 30^\circ + \sin \phi \sin 30^\circ)^2 = \left(\frac{\sqrt{3}}{2} \cos \phi + \frac{1}{2} \sin \phi \right)^2 = \frac{3}{4} \cos^2 \phi + \frac{\sqrt{3}}{2} \cos \phi \sin \phi + \frac{1}{4} \sin^2 \phi$$

$$\sum C_{L_i} = C_N \cdot \left(\sin^2 \phi + \frac{3}{4} \cos^2 \phi - \frac{\sqrt{3}}{2} \cos \phi \sin \phi + \frac{1}{4} \sin^2 \phi + \frac{3}{4} \cos^2 \phi + \frac{\sqrt{3}}{2} \cos \phi \sin \phi + \frac{1}{4} \sin^2 \phi \right) = \frac{3}{2} C_N \cdot (\sin^2 \phi + \cos^2 \phi) = \frac{3}{2} C_N$$

$$\boxed{C_{L_{\text{effective}}} = \frac{N}{2} C_N \rightarrow N = 3}$$

QED!

Example Calculation (3)

Total parameter calculation

Output parameters

DRAG DATA

Nosecone	Fins
CNN	CNF
2	4.30898
XN, cm	XF, cm
32.62	185.741
Conical Transition	Total
CNT	CNR
-1.34694	4.96204
XT, cm	Xcp, cm
116.818	142.733
Static Margin	
1.22093	
Moment Coefficient Data	
Mean Cl-alpha, 1/radian	
4.96204	
Mean Cm-alpha, 1/radian	
-6.44348	
Mean Cm-q, 1/radian/sec	
-0.038475	

CF BASED ON AWET

0.002547

CF BASED ON MAX
CROSS SECTION

0.0529207

BASE DRAG Coeff BASED
MAX CROSS SECTION AREA

0.126062

Compressible BASE DRAG
Coeff Adjusted for Boat tail

0.07091

Nose Cone Profile Drag

0.00935593

Adjusted Total drag Coefficient

0.315467

$$C_{L_\alpha} \approx C_{N_R}$$

$$C_{m_\alpha} = -X_{sm} \cdot (C_{L_\alpha} + C_{D_0}) =$$

$$-1.22093 (4.96204 + 0.315467)$$

$$=-6.44348$$

$$\left(C_{m_q} \right)_0 = -X_{sm}^2 \cdot C_{L_\alpha} \cdot \left(\frac{C_{ref}}{V_{\infty 0}} \right) =$$

$$\frac{(-1.22093^2 (4.96204))}{67.2868} \frac{35}{100}$$

$$=-0.038475$$

Launch Simulation with Pitch

Target 10,000 M
Apogee altitude

Motor Model

gamma
1.2500

A/A*
6.000000

P01, kPa
3500

T01, deg. K
2850

A*, cm
5

MW
25

Nozzle exit
divergence angle, deg
15

FUEL Mass, KG
50

Total mass, kg
105.87

External Forces, Conditions

Thrust, N
2542.6!

Specific Impulse, sec
219.209

g, m/sec^2
9.8067

Mdry
55.87

Iyy, kg-M^2
506.373

Thrust
Off On

Reference Parameters

Aref, cm^2
962.113

cref, cm
35

Iyy/M, M^2
0.38520!

Moment Coefficient Data


Mean Cl-alpha, 1/radian
4.96204

Mean Cm-alpha, 1/radian
-3.43852

Mean Cm-q, 1/radian/sec
-0.038475

Mean CD0
0.315467


slender rod: axis through end

$$I = \frac{1}{3} \cdot M \cdot L^2$$



$$\left(I_{yy}\right)_0 = M_0 \cdot L^2 = 105.87 \cdot 2.15^2 = 506.373_{kg-m^2}$$

Example Calculation, Pitch Sim


PITCH RATE




PITCH Angle



Angle of Attack




C_m




Example Calculation, Pitch Sim (2)


Altitude




Airspeed



Mass,




Thrust




Example Calculation, Pitch Sim (3)


Downrange




Acceleration, g's









Mach Number




CD



Simulation Comparisons



Pitching Moment Control of Vehicle




$$\begin{bmatrix} \dot{\alpha} \\ \dot{q} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} -\frac{\bar{q} \cdot A_{ref}}{m \cdot V} \cdot C_L + q + \frac{g_{(r)}}{V} \cos(\theta - \alpha) - \frac{F_{thrust} \sin \alpha}{m \cdot V} \\ \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_y} \cdot C_m \\ q \end{bmatrix}$$

$$M_y = \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_{yy}} C_m = \frac{\bar{q} \cdot A_{ref} \cdot c_{ref}}{I_{yy}} \left(C_{m(\alpha, q)} + C_{m_d} \cdot \delta \right)$$


Natural Response
Depends on α, q

Controlled Response
Depends on Actuation

Launch (Rocket) Controls





Decoupled Equations of Motion



- *Very loose coupling between longitudinal aerodynamics and pitch dynamics and overall vehicle trajectory*
- Generally pitch dynamics and vehicle trajectory are controlled independently
- Trajectory controlled about some Prescribed $\theta_0(t)$ (outer loop)
- Pitch tracking controlled about nominal $\theta_0(t)$ (inner loop)

Example Control Strategies




Questions??



Appendix I: Derivation of the Longitudinal “AlphaDot” Equation

- **Body Axis Coordinates, Position and Airspeed Components**


$$\vec{V}_{\infty} = u \cdot \vec{i} + v \cdot \vec{j} + w \cdot \vec{k} \equiv \begin{bmatrix} u \\ v \\ w \end{bmatrix}$$



Derivation of the Longitudinal “AlphaDot” Equation (2)

- Body Axis Coordinates, Angular Rate Components

$$\vec{\Omega} = p \cdot \vec{i} + q \cdot \vec{j} + r \cdot \vec{k} \equiv \begin{bmatrix} p \\ q \\ r \end{bmatrix}$$



Derivation of the Longitudinal “AlphaDot” Equation (3)


$$\begin{bmatrix} p \\ q \\ r \end{bmatrix} = \begin{bmatrix} \dot{\phi} \\ 0 \\ 0 \end{bmatrix} + \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos\phi & \sin\phi \\ 0 & -\sin\phi & \cos\phi \end{bmatrix} \cdot \begin{bmatrix} 0 \\ \dot{\theta} \\ 0 \end{bmatrix} + \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos\phi & \sin\phi \\ 0 & -\sin\phi & \cos\phi \end{bmatrix} \cdot \begin{bmatrix} \cos\theta & 0 & -\sin\theta \\ 0 & 1 & 0 \\ \sin\theta & 0 & \cos\theta \end{bmatrix} \cdot \begin{bmatrix} 0 \\ 0 \\ \dot{\psi} \end{bmatrix}$$

$$= \begin{bmatrix} 1 & 0 & -\sin\phi \\ 0 & \cos\phi & \cos\theta\sin\phi \\ 0 & -\sin\phi & \cos\theta\cos\phi \end{bmatrix} \cdot \begin{bmatrix} \dot{\phi} \\ \dot{\theta} \\ \dot{\psi} \end{bmatrix} = \begin{bmatrix} \dot{\phi} - \sin\phi \cdot \dot{\psi} \\ \cos\phi \cdot \dot{\theta} + \cos\theta\sin\phi \cdot \dot{\psi} \\ -\sin\phi \cdot \dot{\theta} + \cos\theta\cos\phi \cdot \dot{\psi} \end{bmatrix}$$



$$\begin{bmatrix} \dot{\phi} \\ \dot{\theta} \\ \dot{\psi} \end{bmatrix} = \begin{bmatrix} 1 & \tan\theta\sin\phi & \tan\theta\cos\phi \\ 0 & \cos\phi & -\sin\phi \\ 0 & \sin\phi/\cos\theta & \cos\phi/\cos\theta \end{bmatrix} \cdot \begin{bmatrix} p \\ q \\ r \end{bmatrix} = \begin{bmatrix} p + q \cdot \tan\theta\sin\phi + r \cdot \tan\theta\cos\phi \\ q \cdot \cos\phi - r \cdot \sin\phi \\ q \cdot \sin\phi/\cos\theta + r \cdot \cos\phi/\cos\theta \end{bmatrix}$$

• Euler Angles



Derivation of the Longitudinal “AlphaDot” Equation (4)

- From Dynamics

$$\frac{\vec{F}}{m} = \vec{A} = \frac{d}{dt}(\vec{V}) + \vec{\Omega} \times \vec{V} \rightarrow \frac{1}{m} \begin{bmatrix} F_x \\ F_y \\ F_z \end{bmatrix} = \frac{d}{dt} \begin{pmatrix} u \\ v \\ w \end{pmatrix} + \begin{vmatrix} \vec{i} & \vec{j} & \vec{k} \\ p & q & r \\ u & v & w \end{vmatrix}$$

$$\rightarrow \begin{bmatrix} \dot{u} \\ \dot{v} \\ \dot{w} \end{bmatrix} = - \begin{vmatrix} \vec{i} & \vec{j} & \vec{k} \\ p & q & r \\ u & v & w \end{vmatrix} + \frac{1}{m} \begin{bmatrix} F_x \\ F_y \\ F_z \end{bmatrix}$$

- Evaluating Cross Product

$$\begin{bmatrix} \dot{u} \\ \dot{v} \\ \dot{w} \end{bmatrix} = \begin{bmatrix} 0 & r & -q \\ -r & 0 & p \\ q & -p & 0 \end{bmatrix} \cdot \begin{bmatrix} u \\ v \\ w \end{bmatrix} + \frac{1}{m} \begin{bmatrix} F_x \\ F_y \\ F_z \end{bmatrix}$$


Derivation of the Longitudinal “AlphaDot” Equation (5)

- Assume Axi-Symmetric Missile Profile, 2-D Flight Path

$$(v, \beta, F_y = 0, V_\infty = \sqrt{u^2 + w^2})$$

- Translational EOM Reduce to

$$V_\infty = \sqrt{u^2 + w^2} \rightarrow \begin{cases} \dot{u} = -q \cdot w + \frac{F_x}{m} \\ \dot{w} = q \cdot u + \frac{F_z}{m} \end{cases}$$



→ From Kinematics

$$\tan \alpha = \frac{w}{u} \rightarrow (1 + \tan^2 \alpha) \dot{\alpha} = \frac{\dot{w}}{u} - \frac{w}{u^2} \cdot \dot{u} = \frac{\dot{w} \cdot u - \dot{u} \cdot w}{u^2}$$

$$(1 + \tan^2 \alpha) = \left(1 + \left(\frac{w}{u} \right)^2 \right) = \frac{u^2 + w^2}{u^2} \rightarrow \dot{\alpha} = \frac{u^2}{u^2 + w^2} \cdot \frac{\dot{w} \cdot u - \dot{u} \cdot w}{u^2} = \frac{\dot{w} \cdot u - \dot{u} \cdot w}{u^2 + w^2}$$

$$\dot{\alpha} = \frac{\dot{w} \cdot u - \dot{u} \cdot w}{u^2 + w^2} = \frac{\dot{w} \cdot u}{u^2 + w^2} - \frac{\dot{u} \cdot w}{u^2 + w^2}$$


Derivation of the Longitudinal “AlphaDot” Equation (6)

→ From Kinematics

$$\dot{\alpha} = \frac{\dot{w} \cdot u - \dot{u} \cdot w}{u^2 + w^2} = \frac{\dot{w} \cdot u}{u^2 + w^2} - \frac{\dot{u} \cdot w}{u^2 + w^2}$$

→ From Dynamics

$$\begin{cases} \dot{u} = -q \cdot w + \frac{F_x}{m} \\ \dot{w} = q \cdot u + \frac{F_z}{m} \end{cases}$$



→ Substitute

$$\dot{\alpha} = \frac{\left(q \cdot u + \frac{F_z}{m} \right) \cdot u}{V_\infty^2} - \frac{\left(-q \cdot w + \frac{F_x}{m} \right) \cdot w}{V_\infty^2} = \frac{\left(q \cdot u^2 + \frac{F_z}{m} \cdot u + q \cdot w^2 - \frac{F_x}{m} \cdot w \right)}{V_\infty^2} = \frac{\left(q \cdot (u^2 + w^2) + \frac{F_z}{m} \cdot u - \frac{F_x}{m} \cdot w \right)}{V_\infty^2}$$

→ Simplify

$$\dot{\alpha} = \frac{\left(q \cdot V_\infty^2 + \frac{F_z}{m} \cdot u - \frac{F_x}{m} \cdot w \right)}{V_\infty^2} = \frac{\left(q \cdot V_\infty^2 + \frac{F_z}{m} \cdot u - \frac{F_x}{m} \cdot w \right)}{V_\infty^2} = \left(q + \frac{F_z}{m \cdot V_\infty} \cdot \frac{u}{V_\infty} - \frac{F_x}{m \cdot V_\infty} \cdot \frac{w}{V_\infty} \right)$$

Derivation of the Longitudinal “AlphaDot” Equation (7)

kinematics


$$\rightarrow \left[\begin{array}{l} \frac{u}{V_\infty} = \cos \alpha \\ \frac{w}{V_\infty} = \sin \alpha \end{array} \right] \rightarrow \dot{\alpha} = \left(q + \frac{F_z}{m \cdot V_\infty} \cdot \cos \alpha - \frac{F_x}{m \cdot V_\infty} \cdot \sin \alpha \right)$$

→ *Resolving Forces*


$$\left[\begin{array}{l} F_x = T_{thrust} - m \cdot g \cdot \sin \theta - D_{rag} \cdot \cos \alpha + L_{ift} \cdot \sin \alpha \\ F_z = m \cdot g \cdot \cos \theta - D_{rag} \cdot \sin \alpha - L_{ift} \cdot \cos \alpha \end{array} \right]$$

→ *Substituting*

$$\dot{\alpha} = \left(q + \frac{m \cdot g \cdot \cos \theta - D_{rag} \cdot \sin \alpha - L_{ift} \cdot \cos \alpha}{m \cdot V_\infty} \cdot \cos \alpha - \frac{T_{thrust} - m \cdot g \cdot \sin \theta - D_{rag} \cdot \cos \alpha + L_{ift} \cdot \sin \alpha}{m \cdot V_\infty} \cdot \sin \alpha \right)$$



Derivation of the Longitudinal “AlphaDot” Equation (7)



$$C_L = \frac{L_{ift}}{\frac{1}{2} \cdot \rho \cdot V^2 \cdot A_{ref}}, \quad C_D = \frac{D_{rag}}{\frac{1}{2} \cdot \rho \cdot V^2 \cdot A_{ref}}$$

C_L = lift coefficient, C_D = drag coefficient

$\frac{1}{2} \cdot \rho \cdot V^2$ = "dynamic pressure" ($\bar{q}$)

A_{ref} = "reference area" → typically maximum frontal area

ρ = "local air density" → function of altitude

→ Collecting

$$\dot{\alpha} = q + \frac{m \cdot g \cdot \cos \theta \cdot \cos \alpha + m \cdot g \cdot \sin \theta \cdot \sin \alpha}{m \cdot V_{\infty}} + \frac{-D_{rag} \cdot \sin \alpha \cdot \cos \alpha + D_{rag} \cdot \cos \alpha \cdot \sin \alpha}{m \cdot V_{\infty}} - \frac{L_{ift} \cdot \cos^2 \alpha + L_{ift} \cdot \cos^2 \alpha}{m \cdot V_{\infty}} - \frac{T_{thrust} \cdot \sin \alpha}{m \cdot V_{\infty}}$$

→ Simplifying

$$\dot{\alpha} = q + \frac{g \cdot \cos(\theta - \alpha)}{V_{\infty}} - \frac{L_{ift}}{m \cdot V_{\infty}} - \frac{T_{thrust} \cdot \sin \alpha}{m \cdot V_{\infty}} \rightarrow \boxed{\dot{\alpha} = q + \frac{g \cdot \cos(\theta - \alpha)}{V_{\infty}} - \frac{\bar{q} \cdot A_{ref} \cdot C_L + T_{thrust} \cdot \sin \alpha}{m \cdot V_{\infty}}}$$

Appendix II: Derivation of the Longitudinal “VDot” Equation

Kinematics

$$\dot{V}_{\infty} = \frac{1}{2\sqrt{u^2 + w^2}} \cdot (2 \cdot u \cdot \dot{u} + 2 \cdot w \cdot \dot{w}) = \left(\frac{u \cdot \dot{u} + w \cdot \dot{w}}{\sqrt{u^2 + w^2}} \right) =$$

$$\left(\frac{u \cdot \left(-q \cdot w + \frac{F_x}{m} \right) + w \cdot \left(q \cdot u + \frac{F_z}{m} \right)}{V_{\infty}} \right) = \left(\frac{u}{V_{\infty}} \cdot \frac{F_x}{m} + \frac{w}{V_{\infty}} \cdot \frac{F_z}{m} \right) = \cos \alpha \cdot \frac{F_x}{m} + \sin \alpha \cdot \frac{F_z}{m}$$

→ *Resolving Forces*

$$\begin{bmatrix} F_x = T_{thrust} - m \cdot g \cdot \sin \theta - D_{rag} \cdot \cos \alpha + L_{ift} \cdot \sin \alpha \\ F_z = m \cdot g \cdot \cos \theta - D_{rag} \cdot \sin \alpha - L_{ift} \cdot \cos \alpha \end{bmatrix}$$

Substituting

$$\dot{V}_{\infty} = \cos \alpha \cdot \frac{(T_{thrust} - m \cdot g \cdot \sin \theta - D_{rag} \cdot \cos \alpha + L_{ift} \cdot \sin \alpha)}{m} + \sin \alpha \cdot \frac{(m \cdot g \cdot \cos \theta - D_{rag} \cdot \sin \alpha - L_{ift} \cdot \cos \alpha)}{m}$$

Derivation of the Longitudinal “VDot” Equation

Simplifying

$$\dot{V}_{\infty} = \cos \alpha \cdot \frac{(T_{thrust} - m \cdot g \cdot \sin \theta - D_{rag} \cdot \cos \alpha)}{m} + \sin \alpha \cdot \frac{(m \cdot g \cdot \cos \theta - D_{rag} \cdot \sin \alpha)}{m} =$$

$$\dot{V}_{\infty} = \cos \alpha \cdot \frac{(T_{thrust} - m \cdot g \cdot \sin \theta - D_{rag} \cdot \cos^2 \alpha)}{m} + \sin \alpha \cdot \frac{(m \cdot g \cdot \cos \theta - D_{rag} \cdot \sin^2 \alpha)}{m} =$$

$$\frac{T_{thrust} \cdot \cos \alpha}{m} + g \cdot (\cos \theta \sin \alpha - \sin \theta \cos \alpha) - \frac{D_{rag}}{m} (\cos^2 \alpha + \sin^2 \alpha) =$$

$$\frac{T_{thrust} \cdot \cos \alpha}{m} + g \cdot (\cos \theta \sin \alpha - \sin \theta \cos \alpha) - \frac{\bar{q} \cdot A_{ref} \cdot C_D}{m} = -\frac{\bar{q} \cdot A_{ref} \cdot C_D}{m} - g \cdot \sin(\theta - \alpha) + \frac{T_{thrust} \cdot \cos \alpha}{m}$$

$$\dot{V}_{\infty} = \frac{T_{thrust} \cdot \cos \alpha}{m} - g \cdot \sin(\theta - \alpha) - \frac{\bar{q} \cdot A_{ref} \cdot C_D}{m}$$